

RF Wireless Remote Control Radio Controller / Transmitter & Receiver

Package Include:

1 x Receiver: S2PU-AC220-ANT2 (2 Channel / Four Control Modes)
1 x Transmitter: CB-2
1 x User manual

Features:

Wireless control, easy to install

Control Lights, Motors, Fans, electrically operated Doors/Locks/Windows/Blinds/Cars or Other Appliances with voltage AC110~240V or DC0~28V.
Universal input: support voltage of AC110V (100V~120V), widely used in US, Canada... and voltage of AC220V (200V~240V), used in UK, France...

You can turn on/off the receiver with transmitter (remote control) from any place within a reliable distance; the wireless RF signal can pass through walls, floors and doors.

With characteristics of reverse power protection and over current protection

Audible / visual indication

Use microcontroller model of EM78P156, an 8-bit microprocessor designed and developed with low-power and high-speed CMOS technology.

Use ULN2003 to drive relay, with strong anti-interference.

Reliable control: The transmitter (Encoding) and the receiver (Decoding) use an 8-bit code.

One/several transmitters can control one/several receivers simultaneously.

If you use two or more receivers in the same place, you can set them with different codes.

Transmitting Frequency: 315MHz / 433MHz

Receiver:

Model No.: S2PU-AC220-ANT2

Control Mode: Toggle, Momentary, Latched, Momentary + Toggle

Coding Type: Fixed code / learning code

Coding Setting: By learning

Power Supply (Operating Voltage): AC100~240V

Working Voltage Range of Relay: DC 0-28V/ AC110~240V

PCB Size: 94mm x 73mm x 25mm

Case Size: 100mm x 80mm x 30mm

Maximum Working Current: 30A / each channel

External Extend Antenna:

Frequency Range: 300~450MHz

Impedance: 50Ω

Antenna Length: 15cm

Cable Length: 150cm

Weight: 35g

Anti-interference, waterproof, shielded wire set inside

Magnetic stand design for easy to install

Transmitter:

Model No.: CB-2

Channel: 2 CH

Remote Control Distance: 1000m / 3000ft (theoretically)

Encode: Fixed code by soldering

Unit size: 135mm x 42mm x 25mm

Power Supply: 1 x 6F22-9V battery (included, can be used for 12 months)

Usage:

Setting different control modes (We have set the receiver as Toggle control mode before delivery. If you want to use other control modes, do as following operation):

Setting control mode Toggle: Only connect Jumper-2.

Control mode Toggle: Press -> On; Press again -> Off.

Press big button of remote: Turn on relay 1 (connect A and B, disconnect A and C)

Press big button again: Turn off relay 1 (disconnect A and B, connect A and C)

Press small button of remote: Turn on relay 2 (connect A and B, disconnect A and C)

Press small button again: Turn off relay 2 (disconnect A and B, connect A and C)

Setting control mode Momentary: Only connect Jumper-1.

Control mode Momentary: Press and hold -> On; Release -> Off.

Press and hold big button of remote: Turn on relay 1 (connect A and B, disconnect A and C)

Release big button: Turn off relay 1 (disconnect A and B, connect A and C)

Press and hold small button of remote: Turn on relay 2 (connect A and B, disconnect A and C)

Release small button: Turn off relay 2 (disconnect A and B, connect A and C)

Setting control mode Latched: Disconnect Jumper-1 and Jumper-2.

Control mode Latched: Press -> On, another relay Off; Press another button -> Off.

Press big button of remote: Turn on relay 1 (connect A and B, disconnect A and C)

Turn off relay 2 (disconnect A and B, connect A and C)

Press small button of remote: Turn on relay 2 (connect A and B, disconnect A and C)

Turn off relay 1 (disconnect A and B, connect A and C)

Setting control mode Momentary + Toggle: Connect Jumper-1 and Jumper-2.

Control mode Momentary (Channel 1): Press and hold -> On; Release -> Off.

Press and hold big button of remote: Turn on relay 1 (connect A and B, disconnect A and C)

Release big button: Turn off relay 1 (disconnect A and B, connect A and C)

Control mode Toggle (Channel 2): Press -> On; Press again -> Off.

Press small button of remote: Turn on relay 2 (connect A and B, disconnect A and C)

Press small button again: Turn off relay 2 (disconnect A and B, connect A and C)

We have learned remote control to the receiver. If you don't want the receiver to work with the remote control, you can delete all codes of remote controls, which are stored in the receiver.

Operation: Press and hold the button of receiver until signal LED flashes slowly; release the button, LED keeps slow flash. That means all stored codes have been deleted successfully.

Learning the button of remote control:

1) Press the button of receiver; signal LED on the receiver keeps shining. The receiver enters into status of LEARNING.

2) Press any one button on remote control. If signal LED flashes quickly 15 times and turns off, it means learning is successful.

3) When receiver is in the status of LEARNING, press again the button of receiver, signal LED turns off, learning process will be discontinued.

4) The receiver can learn several remote controls with different codes.

