

Luggage Anti-Robbery Anti-Theft Anti-Lost Wireless Vibration Alarm

Package Include:

- 1 x Main unit
- 1 x Remote control
- 1 x Charger
- 1 x User manual

Feature:

This is a wireless remote control alarm with alarm sound and 20,000 volt high voltage to prevent the loss of luggage. The product is widely used in the luggage, the suitcase, the password box, the paper bag and other items. With anti-robbery, anti-theft and anti-lost functions. With vibration alarm function. With a ON /OFF switch. Built-in a 4.3-volt lithium battery.

Main Unit Parameters:

Operating Voltage: 4.3V
Working current: 70mA
Operating Frequency: 315 MHz
Alarm: alarm sound and 20,000 volt high voltage (release instantaneously)
Alarm volume of built-in siren: 70dB
Unit Size: 125mm x 80mm x 40mm

Remote Control Parameters:

With Sliding Cover: Slide up when it doesn't work (to protect the button). Slide down the button will appear.
Channel/ Button: 4
Button Symbol: A, B, C, D
Operating Voltage: 12V (1 x 23A -12V battery, can be used for 12 months)
Operating Frequency: 315 MHz
Transmitting Distance: 15~50m / 50~150ft (theoretically)
Operating Temperature: -20 ° C to +70 ° C
Unit Size: 58mm x 39mm x 16mm

Usage:

Button A: Anti-robbery button. Press button A, the main unit sends out the alarm sound and 20,000 volt high voltage.
Button B: Anti-lost button. Press button B, the main unit enters into the anti-lost state. If the main unit detects vibration, it will send out the alarm sound and 20,000 volt high voltage for 30 seconds.
Button C: Anti-theft button. Press button C, the main unit enters into the anti-theft state. When the distance between the main unit and remote control exceed 15M, the main unit sends out the alarm sound and 20,000 volt high voltage.
Button D: Cancel button. Press button D to cancel the alarm.

Note: When the main unit sends out the alarm sound and 20,000 volt high voltage, if put the metal parts of two red wires away from 1CM, they will produce the electric spark.

