

RF Wireless Remote Control Radio Controller / Transmitter & Receiver

Package Include:

1 x Receiver: S1X-AC220
2 x Transmitter: C-2
1 x Electric solenoid valve
1 x User manual

Feature:

Wireless control, easy to install

Control Lights, Motors, Fans, electrically operated Doors/Locks/Windows/Blinds/Cars or Other Appliances with AC 100~240V.

You can turn on/off the receiver with transmitter (remote control) from any place within a reliable distance; the wireless RF signal can pass through walls, floors and doors.

With characteristics of reverse power protection and over current protection

Audible / visual indication

Use microcontroller model of EM78P156, an 8-bit microprocessor designed and developed with low-power and high-speed CMOS technology.

Reliable control: The transmitter (Encoding) and the receiver (Decoding) use an 8-bit code.

One/several transmitters can control one/several receivers simultaneously.

If you use two or more receivers in the same place, you can set them with different codes.

Transmitting Frequency: 315MHz / 433MHz

Receiver:

Model No.: S1X-AC220

Channel: 1 CH

Control Modes: Toggle, Momentary, Latched

Coding Type: Fixed code

Coding Setting: By learning

Power Supply (Operating Voltage): AC100~240V

PCB size: 75mm x 54mm x 22mm

Case size: 79mm x 58mm x 36mm

Maximum Working Current: 10A

Transmitter:

Model No.: C-2

Shell color: white

Channel: 2 CH

Remote Control Distance: 100m / 300ft (theoretically)

Encode: Fixed code by Soldering

Unit size: 58mm x 39mm x 16mm

Power Supply: 1 x 23A -12V battery (included, can be used for 12 months)

Parameters:

Wattage: 24W

Working Voltage: AC 220V

Type: normally closed (power on, solenoid valve open; power off, solenoid valve close)

Working Temperature: -5℃~100℃

Operating Pressure: 0~1.0Mpa (0~10kg/cm²)

Material of valve body and coil: 100% Brass

Usage: water, air, diesel, gas, low viscosity fluids

Pipe size	1/4"	1/2"	3/4"	1"
Thread type	G1/4"	G1/2"	G3/4"	G1"
Internal Orifice	12MM	20MM	25MM	32MM

Usage:

Setting different control modes (We have set the receiver as Toggle mode before delivery. If you want to use other modes, do as following):

1) Setting control mode Toggle: Only connect Jumper-2.

Press button 1: Turn on the relay, terminal OUT outputs AC power. Electric solenoid valve work.

Press button 1 again: Turn off the relay, terminal OUT no output. Electric solenoid valve stops work .

2) Setting control mode Momentary: Only connect Jumper-1.

Press and hold button 1: Turn on the relay, terminal OUT outputs AC power. Electric solenoid valve work.

Release button 1: Turn off the relay, terminal OUT no output. Electric solenoid valve stops work .

3) Setting control mode Latched: Do not connect Jumper-1 and Jumper-2.

Press button 1: Turn on the relay, terminal OUT outputs AC power. Electric solenoid valve work.

Press button 2: Turn off the relay, terminal OUT no output. Electric solenoid valve stops work.

Learning the button of remote control:

1) Press the button of receiver; signal LED on the receiver keeps shining. The receiver enters into status of LEARNING.

2) Press any one button on remote control. If signal LED flashes quickly 15 times and turns off, it means learning is successful.

3) When receiver is in the status of LEARNING, press again the button of receiver, signal LED turns off, learning process will be discontinued.

4) The receiver can learn several remote controls with different codes.

Delete all transmitters:

We have learned remote control to the receiver. If you don't want the receiver to work with the remote control, you can delete all codes of remote controls, which are stored in the receiver.

Operation: Press and hold the button of receiver until signal LED flashes slowly; release the button, LED keeps slow flash. That means all stored codes have been deleted successfully.

